

RBM HoldWash-CR



CEMENT & CLINKER REMOVER

MIXING & APPLICATION INSTRUCTIONS

Ready for Use - No Mixing Required.

Always remember to use proper PPE (refer to SDS).

Use low-pressure application equipment with foaming nozzle to spray directly onto the surface.

Once the desired areas are covered, let the product settle in for a minimum of 20 minutes. If foam is becoming dry due to hot temperatures or wind, mist water on the desired area without removing the foam.

After 20 minutes have passed, lightly brush the area then rinse with the highest pressure water available. Product and residues will rinse off with little effort.

If residues remain, reapply product and repeat instructions above.

PRECAUTIONS

Prevention: If medical advice required, keep container or label at hand • Keep out of reach of children • Read label before use • Do not handle until all safety precautions have been understood • Wash hands thoroughly after handling • Do not eat, drink, or smoke when using this product • Wear protective gloves, eye, and face protection • Keep container tightly closed.

Response: IF SWALLOWED: Call POISON CENTER or doctor if you feel unwell. Rinse mouth • IF ON SKIN: Wash with plenty of water • IF SKIN IRRITATION OCCURS: Get medical advice/attention • IF IN EYES: Rinse with water for several minutes. Remove contact lenses, if easy to do so. Continue rinsing • IF EYE IRRITATION PERSISTS: Get medical attention • Absorb spillage to prevent material damage.

Storage: Store in well-ventilated area. Keep container tightly closed.

Disposal: Dispose content/container in accordance with applicable laws and regulations, and product characteristic at time of disposal.

See Safety Data Sheet
for this product



EQUIPMENT SETUP & NOTES

Bleed the vessel's air lines before connecting the pump. Weight the suction hose to keep secure at the bottom of the drum. Before connecting the outlet hose, secure it to avoid tension on the pump. Take extra precautions with hose connections. Loop the wand hose with the outlet hose to prevent fittings from disconnection.

Always start the pump with all hoses on deck to ensure no leaks. Use a heaving line to lower equipment into the holds. Ensure the PowerWand tip is facing up.

HOW LONG TO SOAK?

Suggested time is 20 minutes. More time may be required for heavier residues. Determine the size of sections to clean & soaking time by the current weather conditions. Clean small sections in warm climates. In cooler climates, clean larger sections.

GENERAL DISCLAIMER & SAFETY GUIDELINES

Handle with Extreme Care: Acids can cause severe burns, blistering, and permanent scarring upon contact. **Protective Equipment Required:** Always wear appropriate personal protective equipment (PPE), including chemical-resistant gloves, safety goggles or face shields, and lab coats.

Ventilation: Work in a well-ventilated area, preferably a fume hood, to avoid breathing in vapours or mists.

Storage: Store in cool, dry areas, away from incompatible materials like bases, metals, and oxidizers.

First Aid: In case of contact, immediately flush skin or eyes with water for at least 15 minutes and seek medical attention.

These instructions are based on our best understanding of safe handling. However, the user is responsible for ensuring compliance with all local, regional, and national safety regulations. We cannot be held liable for misuse, negligence, or accidents resulting from the use of this information.

 **RBM**[®]
HOLDSOLUTIONS

— ESTABLISHED 1999 —

+1 604 531 8333 (24 hrs) www.holdsolutions.com

The above recommendations and instructions are based on past experiences. There is no scientific formula to determine the required amount of RBM HoldWash-CR for each vessel. Several conditions can affect the required amount; such as the ability, efficiency and experience of crew, hold conditions, weather conditions, application height and equipment used.